
VIDEO MODULE PRODUCT MANUAL





7" Screen

- IPS LCD screen
- 2GB memory
- Battery (3.7V 4.2V, 1500mAh) included, up to
 2 hours battery life
- Recharging time from 3 to 4 hours
- Type A USB cable for charging and file transfer





10" Screen

- IPS LCD screen
- 4GB memory
- Battery (3.7V 4.2V, 1500mAh) included, up to
 2 hours battery life
- Recharging time from 3 to 4 hours
- Type A USB cable for charging and file transfer

HOW TO UPLOAD VIDEO, PHOTOS AND MUSIC

- Connect the video module to a computer (Mac or PC) by using the included USB cable.
- After the USB cable is plugged into your computer, a flash drive icon will appear on the desktop (Mac) or a dialog box may appear (PC). If it doesn't, open "My Computer" and select the flash drive.
- Copy the video file (.mp4/.avi/.rmvb/.mov/.mpg) into the Video folder.
- Copy photos (.jpg) into the Photo folder.
- Copy the music file (.mp3/.wma) into the Music folder.

The image or video aspect ratio must be 16:9 (widescreen) to avoid distortion.